

Pipe Pro Installation

Pipe Prop is fast and easy to install, just one of the reasons you'll find it used on some of the finest structures in the country.

You'll only need three other elements in addition to the Saddle, PVC Pipe and Base:

1. PVC glue
2. PVC pipe cutter (ratchet-style recommended)
3. Manufacturer-recommended roofing adhesive

Installation is quick and easy:

1. Cut the pipe to the correct length. Apply PVC glue to the pipe and attach the saddle base and conduit.
2. Position Pipe Prop where you need it according to building codes.
3. Attach to roof according to the roofing manufacturer's recommendations.
4. Lay the pipe in the saddle and secure in place with one nylon cable tie (provided). When Pipe Prop's base is installed properly, the bond formed is almost indestructible, making Pipe Prop's secure anchoring ability even more formidable.



All you need to assemble Pipe Prop.



Cut the length of pipe you need.



Space according to local codes.



Only one nylon tie is necessary to secure pipe to Pipe Prop.