AM-ST100-0623

**USER MANUAL**

▶ **Read instructions carefully before operating this system.**

⚠️ WARNING

1. Do not use the device in flammable and explosive environments.

2. Avoid using the device in extremely cold, hot or humid environments; Otherwise, the device may be damaged, and the damage caused by this behavior is not covered by the warranty.

3. Use it with care to prevent the device from falling from a height. Do not throw, beat or press the device.

4. Avoid using parts from other manufacturers, so as to damage the device due to incompatibility.

5. If the user disassembles the device without permission, the damage caused by such behavior is not covered by the warranty.

6. **Do not mix battery charging cables and power cables, otherwise the battery will be damaged or the system will not work properly.**

7. Do not overcharge the lithium battery, otherwise it may cause damage.

8. Please only use our company's dedicated charger for charging.

9. There are restrictions on the use of the device. Observe whether the device is in a high-intensity magnetic field environment. For example, the magnetic field generated during the operation of an electric screwdriver can significantly affect the accuracy of the meter. Please keep the device away from high-intensity magnetic field environments for use or storage.

10. When you are using the product, if you find that the battery of the product is exhausted, the last green light on the power indicator of the product will flash. At this time, you should turn off the product and charge it in time. Avoid overusing the battery to prevent charging failures.

CONTENTS

Understanding AM-MINI

1. Power ON/OFF

2. DC- Jack

3. Fuse

4. Operating Status Indicator: Pressing the power button activates a steady green light, indicating the device is in normal operation.

5. Charging status indicator light: The red light remains on during charging, and the green light remains on when fully charged.

Mobile Phone Viewing App Function

Android/Apple iOS operating process:

1.   Scan the QR code below with your phone or tablet, or search and download "ulinkCamera" from the software store to install the latest version of the APP.

2.   Turn on the power switch.

3.   Open your phone, enter the "Settings" interface, select "WLAN", find the WiFi"WiFi_XXXXXX"corresponding to the device ,and enter the WiFi password "12345678".

4.   Open the app and click "Enter Now" to view the real-time screen.

5.   Note: Please refer to Attachment 1 for specific operations.

①   **Scan the QR code below with your phone or tablet to install the latest version of the APP.**

Google（Android）

Apple(IOS)

②   **Turn on the power**

SEETEK

③ **Clicking on Settings to enter WIFI connection settings, selecting the device, enter the password to connect successfully.**

WIFI System Operation Guide

Quick Start of WIFI System

① Camera operation interface: Up, Down, Left, Right, Rst(Reset).

SEETEK

② Brightness adjustment of LED lights: increase (slide right), decrease (slide left).

③ The camera pull distance value is displayed. Display overlay in the video.

④ Horizontal/vertical screen switching. (Not supported on iOS system)

⑤ Switch between metric and imperial systems.

⑥ Reset the meter count to zero.

⑦ Erase text and drawings

⑧ Free draw

⑨ Text overlay editing. Display overlay in the video.

⑩ Display the date and time recorded in the video.

⑪ Power level display.

⑫ Video recording function. After clicking on it, there are recording pause and recording end functions .

⑬ Take screenshots of the video.

⑭ MIC icon. Press the microphone icon to turn on or off .

⑮ File Management: After opening, you can replay recorded videos and view saved images after taking photos and screenshots. Select "Manage" to choose to delete or share the corresponding files.

⑯ Select to adjust the width and color when drawing, as well as text size and color.

⑰ Return button to exit the page.